



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0450-0216
Planetary Hub-10 Holes



BL-0450-10216
Planetary Hub



BL-0450-10221
Planetary Hub Inner



BL-0450-12401
Planetary Hub



BL-0450-10207
Planetary Hub



BL-0450-10221
Planetary Hub Inner



Planetary Gear
Set



BL-0450-10204
Carrier



BL-0450-10207
Carrier

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara

Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16

e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0450-10205
Annulus Ring Gear



BL-0450-10206
Planetary Gear



BL-0450-12403
Gear Sun



BL-0448-03902
Trunnion



BL-0458-20040
Knuckle



BL-020-923327
Pump



BL-0448-42602
Knuckle



BL-0448-42603
Knuckle

BL-0458-20041
Knuckle

BL-0331-21614
Kingpost Housing

BL-0120-40301
Kingpost Housing

İmalatımız
mevcuttur

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0445-64301
Gear 38th



BL-02-202043
Case Timing



BL-0445-70501
Layshaft



BL-445-64401
Gear 36th



BL-002-200877
Pulley



BL-002-200018
Pulley



BL-0923-02700
Oil Cooler



BL-0923-04800
Oil Cooler



BL-04-600864
Kit Drive Plate

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0450-10409
Housing



BL-0453-00104
Brake Piston



BL-0450-27200
Yoke



BL-0445-10703
Yoke



BL-0914-86602
Rear Axle Long



BL-0914-89501
Rear Axle Short



BL-0450-10800
Differential Housing



BL-0450-11000
Differential Gear Set



BL-002-200502
Elbow

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0121-55900
Link



BL-0122-92400
Link



BL-0123-04275
Pivot Casting



Buckets
40-50-100 cm



Buckets
60 cm



Buckets
100 cm



BL-0G65-00
Bearing



BL-0331-46249
Bumper



BL-0331-46249
Bumper

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0331-39996
Step Long



BL-0331-27034
Step Short



BL-0445-64401
Plug-Tapa



BL-082-00425
Plug Tapered



BL-0123-06022
Bracket



BL-0123-06022
Bracket NM



BL-0123-06408
Pad Lower



Stop Lamp
Guard



BL-0123-03215
Pad

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0811-20061
Pin



BL-0911-12400
Pin



BL-0811-20053
Pin



BL-0811-80014
Pin



BL-811-50365
Pin



BL-0811-10062
Pin



BL-0809-40048
Pin



BL-0809-00176
Bearing



BL-0809-00131
Bearing

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara

Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16

e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-032-400301
Bowl Filter Glass



BL-032-908400
Filter Assy.



BL-032-905304
Valve Safety



BL-0121-34400
Reservoir Cap



BL-0123-02755
Knob Base



BL-0123-03138
Mounting Rubber



BL-0123-05403
Strut Window Stay



BL-0123-05404
Strut Window Stay



BL-0331-18441
Mounting Cap

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



BL-0331/28215
Window Strud



BL-0458-20353
Friction Plate.



BL-0530-14001
Pin Hair



BL-0716-30255
Stop Selenoid



Lamp



BL-0123-02950
Fender



BL-0123-02951
Fender



BL-0123-05551
Fender



BL-0123-05550
Fender

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP

Quality Replacement Spare Parts



Stop



Front Plate.



BL0-904-06700
Seal



BL-0828-00196
Oring



BL-0834-00448
Hose Top



BL-0834-00263
Hose



BL-0828-00155
Oring



BL-0828-00154
Oring



BL-0813-00360
Gasket Hyraulic Tank

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP- CARRARO

Quality Replacement Spare Parts



BL-0066855
Planet Kit



BL-0066855
Planet Kit



BL-0131824-135947
Gear Group



BL-0811/80014
Pin



BL-0811/50365
Pin



BL-0131825
Carrier



BL-0145264
Housing LH



BL-0145265
Housing RH



BL-0128880
King Pin

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com

All Part Numbers and Symbols are Reference Purpose Only Its not Implied Parts Are Original



CELIKSAN GROUP

Quality Replacement Spare Parts



FILTER PU
FILTER AIR



BL-0322-02601
FILTER AIR



BL-032-925915
FILTER



BL-002-100073
FILTER



BL-0322-02602
FILTER AIR



BL-032-925694
FILTER



BL-0581-18076
FILTER



BL-032-913500
HIDRA.FILTER



BL-0320-04133
FILTER

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com



CELIKSAN GROUP- CARRARO

Quality Replacement Spare Parts



BL-0131825
Carrier



BL-128880
King Pin



BL-066570
PLANETARY HUB



BL-066992
HUB INNER WITH STUD



CELIKSAN GROUP- CARRARO

Quality Replacement Spare Parts



BL-066855
Planet Kit



BL-066855
Planet Kit



BL-0131824-135947
Gear Group



BL-066993
WHEEL HUB



BL-066993
WHEEL HUB



BL-0131825
Carrier



BL-0145264
Housing LH



BL-0145265
Housing RH



BL-0128880
King Pin

Öz Anadolu San.Sit. 665.Sok. No: 39 Ostim-Ankara
Tel: 0 312 395 13 99 - Fax: 0 312 395 49 16
e-mail: celiksan@celiksangroup.com

All Part Numbers and Symbols are Reference Purpose Only Its not Implied Parts Are Original